



Monteer de derailleur zodanig dat de witte kooi net 5 mm onder de bovenste kettinglijn is.



Mount the derailleur such a way that the white cage is just 5 mm under the upper chain line.