

QV - Replacing the oil dampers



- spanner 10
- spanner 10
- LOCTITE 270

Attention:

- Do not hold the damper unprotected with pliers or a vise. If the chrome gets damaged it will start leaking oil!
- Do not push the rod completely into the damper, the oil will come out and the damper is useless!

Get the Panhardrod out of the way (pic. 1) and disassemble the dampers together with the plastic rose joints (pic. 2 a,b).

Put some Loctite 270 on the thread before mounting the plastic rose joints (pic. 3).

Mount the dampers using two spanners 10 mm (pic. 4). The bolt of the rose joints should not be too tight, the nut is there to lock it against the aluminium frame.

You have to be able to rotate the rose joint by hand (pic. 5). However, there may not be noticeable play. The same goes for the Panhard rod.

